


# Simulation of E-Beam Lithography

2D and 3D Simulation  
BEAMER & LAB




- **IMPORTANT NOTICE:** Please note that this session will be recorded. By joining these webinar sessions, you automatically consent to such recordings. If you do not consent to being recorded, do not join the session.
  - Q&A will not be recorded
- **MS Teams essentials (App Users):**
  - Right click on image, use „Pin“ to enlarge
- This webinar / session is an overview / introduction to e-beam lithography simulation
  - Initiated by simulation results presented at Proximity Effect webinar series
  - It picks out essential ingredients, focus on example from Proximity Effect Webinar
  - In case you want / need more depth -> Contact [support@genisys-gmbh.com](mailto:support@genisys-gmbh.com)




- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A

# Electron-Solid Interactions


Incident Electron Beam




TRACER calculates the absorbed energy spread over resist thickness and distance.




- Simulation Result for GaAs wafer with 500nm PMMA resist exposed at 50keV exposure



# Modeling Absorbed Energy




# Absorbed Energy in Resist






- Threshold model assumes
  - 0 development (dissolution) rate < D2C
  - $\infty$  development rate > D2C
  - Resist is clearing at same time for > D2C




**Works well for thin resist & high-contrast**

## 2D Intensity Simulation



# Resist Contour




A constant energy (D2C) is tied to the resist development to where the resist edge will land.



# BEAMER 2D Simulation

## Extended e-beam simulation functions



- Intensity image simulation of multiple regions
  - Easy simulation of additional regions
  - Multiple region selectable by drop-down
- Extended viewing and analysis
  - 2D only, 1D only, 1D + 2D views
  - 1D image at user defined cut-line
  - Matrix-view for loops
- Powerful evaluation
  - Measure image intensity, slope, log slope at 1D view
  - Export data for external evaluation (e.g. Excel, MatLab)




- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A

# 3D e-Beam Lithography Simulation



Layout





E-Beam Exposure



3D PSF




3D Bulk Energy





3D Resist Development

3D absorbed energy in the resist:

- Convoluting the (dose modulated) layout with 3D PSF
- 3D PSF and stack definition need to match





## 3D Energy Modelling



3D resist development model based on development rate model parameter:


- Bulk image intensities are converted in dissolution rate
  - Threshold / Diffused Threshold
  - Development rate model preferred for e-beam lithography
  - MACK 4 Model preferred for optical lithography, but may also be used for e-beam with DNQ type resists
  - CAR Models for chemically amplified resists
- The development front over is modeled removing the resist from top to bottom over development time using a fast marching algorithm
  - Moving in all direction (isotropic “etching”) depending on local dissolution rate

## 3D Resist Modelling





# Development Rate Model

- Typical positive Resist (PMMA) process
  - Exposure is changing resist chemistry (e.g. molecular weight)
  - Dissolution rate is depending on local change of chemistry (e.g. higher rate for lower molecular weight)
  - Development rate is function of developer and temperature



GPC analysis of PMMA950k films







PSI: Schleunitz A., et al. (2014). Novel 3D micro- and nanofabrication method using thermally activated selective topography equilibration (TASTE) of polymers. Nano Convergence. 1. 7. 10.1186/s40580-014-0007-5.

**Simplest way to measure Development Rate: Contrast Curve**




# Measuring Resist Contrast Curve

- Expose pattern of shapes with varying dose
  - Width  $> 3 \times$  Beta or PEC corrected (want flat region)
  - Size easy to measure with profilometer, spectrophotometer ellipsometer, AFM
  - This example, for 100 kV on Si, uses 150  $\mu\text{m}$  x 300  $\mu\text{m}$  rectangles



# Rate Extrapolation

- Development rate table/curve can be generated from the contrast curve






## IMPORTANT:

- Contrast Curve is measured only until D<sub>2C</sub>, binary lithography is using much higher doses (~x2)
- Development rates for higher doses need to be extrapolated (to this Base Dose)
  - How good is this extrapolation? Does it follow a power law, or does it “saturate”?

# Rate Extrapolation

- Development rate table/curve can be generated from the contrast curve




## IMPORTANT:

- Contrast Curve is measured only until D2C , binary lithography is using much higher doses ( ~x2)
- Development rates for higher doses need to be extrapolated (to this Base Dose)
  - How good is this extrapolation? Does it follow a power law, or does it “saturate”?
- Measure CC at shorter development time
  - Identical rate model for both – this supports power law extrapolation beyond the measurable part

$$r = r_0 \left( \frac{D}{D_0} \right)^\gamma$$

$r$  : rate at dose  $D$   
 $r_0$  : rate at dose  $D_0$

# Development Rate with RDA system




Thickness and development time depend on exposure dose




**RDA-800** **LTJ** リソテックジャパン株式会社  
Litho Tech Japan

# Mack Development Model


Some Typical Mack Development Rate Parameters



fit of experimental data with Mack model



3D resist simulation vs. experiment after resist parameter calibration



Simulation

# LAB Simulation: Origin of Lateral Development

LAB

File Edit View Help

Cut Copy Paste Up Save Variables Run Run To Cancel Pause Resume Reset Material Database

Modules Flow Libraries Examples

new flow X

**Layout & Data Handling**

Import Import 3D Edit

Export Export 3D

**Simulation**

Proximity Projection Laser

E-Beam 3D Resist Etching

Metrology Model-OPC Rule-OPC

**Layout Operation**

Extract Transform Grid

Heal NOT Bias

OR AND XOR




P-XOR MINUS Filter

Mapping Merge FDA

In GDSII


E-Beam 3D

Resist




- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A

# Shape PEC Principle



Shape PEC goal:  
Move edges locally to compensate for short- and mid-range energy loss and obtain a uniform dose at all layout edges.






In a DRC step all edge segments are analyzed for the CD and distance to adjacent shapes. A set of representative evaluation points (+) is defined.



Move for all PEC segments (eval. points) are **iteratively** adjusted.





- Simulation is carried out for 100keV electron exposure on 200nm PMMA on GaAs substrate
- The PSF varies with beam scattering into the resist.
- 20% more energy at the bottom for unexposed area.





- What matters the backscattering: substrate material
  - The resist profile enhancement is more apparent for GaAs substrate.


**Dose PEC**




**ODUS  
(overdose = 2)**



**Cumulative energy of PSF**




- < 20
- 20-40
- 40-60
- > 60





# Application: Single Layer Lift-off

## Base dose effect on CD




Bigger lift-off process window when using ODUS (resist edge-slope)





# Simulated CD Sensitivity

- In theory, the enhanced image contrast results in enhanced CD sensitivity.
- The CD change with 5% exposure dose is compared for PEC and ODUS.
- With negative resist profile for ODUS(overdose = 2), the CD change at the resist top is responsible for patterns from lift-off technique. The CD change for positive resist profile (PEC) is decided at the resist bottom.







	Position	Simulated CD change
Dose PEC	Resist bottom	16 nm
ODUS (overdose = 2)	Resist Top	6 nm




- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A

# Multi Layer Resist Process


- Exposure may consist of multiple (e.g. two) „target“ layers
- PEC needs to adjust to two targets




- D2C of resist 1 at one exposure layer
- D2C of resist 2 at other exposure layer




# Application Case: Dolan Bridge



E-beam Simulation




After Development



Evaporation with 2 angle

- Combination of multi-layer resist and dose steps on the wing.
- Energy and resist development front after BEAMER correction

## Application Case: T-Gate










- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A

- Grayscale lithography requires
  - Adjust absorbed energy at all location
  - Consider contrast curve (development rate) for target
  - Consider proximity effect, also over z (resist thickness)
  - Consider 3D development front


# 3D Grayscale



x - z Absorbed Energy




Contrast Curve



Lateral Development

- Isolated shapes develop independently, with development rate depending on exposure dose
- When regions of different dose are adjacent, as in 3D lithography, the regions have a large interaction, and lateral development correction is essential if you want the correct height in each

## Lateral Development



- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A

- Absorbed energy simulation of e-beam lithography is straight forward
  - Electron scattering PSF is modelled well by Monte-Carlo simulation
  - Absorbed energy in the resist is computed by convolution of PSF with the (dose modulated) layout
  - Absorbed image analysis enables optimization of litho quality (image contrast, cd/dose sensitivity)
  - 1st level approach: x-y resist contour can be modelled using threshold model using
- 3D e-beam simulation including resist development process
  - Absorbed energies are transferred to dissolution rate using Development Rate Model
  - Development Rate Curve can be generated from Contrast Curve
  - Development front over development time is simulated using a fast marching with local development rates
- Application example for 3D e-beam simulation
  - Density dependent lateral development
  - Overdose-Undersize (ODUS) for improved resist profile
  - Multi-layer resist processes: Dolan Bridge, T-Gate with shaped wing
  - Greyscale (3D) lithography

- E-Beam Exposure Simulation
- 3D Resist Development Simulation
  - 3D Simulation using LAB
  - Lateral development effect
- Over-Dose-Under-Size ODUS
- Multi Layer Resist Processes
- Greyscale (3D) Lithography
- Summary
- Q&A